



Post Print Polyart Care

Allow Polyart to acclimate to the press room conditions prior to opening and printing.

Allow 24 hours of acclimation time under normal conditions.

Allow 48 hours of acclimation time in extreme cold conditions.

Press room temperature should be at least 70 degrees F and a relative humidity of at least 50%

Once Polyart has had sufficient acclimation time, then the boxes should be opened for loading. Wind Polyart very well while stacking.

When setting up the feeder, be conscious of the side guide burr if the back up will be in your image area. Set the feed wheels to the lightest settings allowed to maintain proper feed. Make sure the sheet smoothers are not set to tight, this can cause pre-mature scratching on the backside from the head stops.

If a new model offset press is used, assure you have the least amount of air suction, but still maintain proper sheet transport and side guide pull.

When setting up the delivery, assure that the back and side joggers are set to the lightest touch and a proper gripper release point to avoid the substrate from sliding in.

Advice in this document is based on practical field experience and is given in good faith but Arjobex, the manufacturer of Polyart synthetic papers, may not be held liable for loss or damage arising from action based on this information. Arjobex recommends all qualifications be conducted with our technical team.

