



## Anti Set-Off Spray Powders For Use With Polyart In The U.S.

The use of anti set-off spray powder is essential when offset printing with conventional inks. Both coated and uncoated spray powders work well with Polyart. Polyart may be printed with spray powders ranging from 15 micron to 55 micron.

Best results can be achieved using powders in the 35micron to 45 micron range. The following spray powders are in that range.

### Spray Rite

300

C-300

350

C-350

A4

LD352

SW350

450

C-450

SW430

### Micromark

35

42

### Electro Sprayer

65

65C

65A

35LD

### Printers Service

400-OX

### Anchor-Lith Kenuco

035

045

### Varn

A-35

C-350

### Oxy-Dry

662

5919

SW-30

440

### OMC

332

425,440

### PAI

65

### ATF

105

*Advice in this document is based on practical field experience and is given in good faith but Arjobex, the manufacturer of Polyart synthetic papers, may not be held liable for loss or damage arising from action based on this information. Arjobex recommends all qualifications be conducted with our technical team.*

